

CONTACTORS

IEC Type Contactors, Starters, and Overload Relays

Common Uses:

Tower Control: 40057, 92910, 92911, 89648, 89642

Main Panel: 40062, 40064

Booster Pump: 40062, 40064, 92906, 92907

IEC Contactors


NI Part #	Description
40057	25 FLA, 4 pole, 110V coil, Contactor only
40059	25 FLA, 4 pole, 480V coil, Contactor only



40057


IEC Interlocked Contactors

NI Part #	Description
40062	25 A, 4 pole, 110V, Reversing, Interlocked, IEC 7.5 hp
40064	25 A, 4 pole, 480V, Reversing, Interlocked, IEC 7.5 hp



IEC Starters

NI Part #	Description
92904	25 A, 4 pole, 480V, 1 hp IEC Contactor & Overload
92905	25 A, 4 pole, 480V, 1-1/2 hp IEC Contactor & Overload
92910	25 FLA, 4 pole, 110V coil - Contactor & Overload, 1 hp
92911	25 FLA, 4 pole, 110V coil - Contactor & Overload, 1-1/2 hp
92906	IEC Reverse Contactor & Overload, 480V
92907	IEC Reverse Contactor & Overload, 110V



IEC Direct-Mount Overload Relays



89670

NI Part #	Description
89670	Relay, Overload, 1 hp
89671	Relay, Overload, 1-1/2 hp

IEC Independent-Mount Overload Relays



89642

NI Part#	Description
89655	Relay, Overload, 1/3 hp
89648	Relay, Overload, 1 hp
89642	Relay, Overload, 1-1/2 hp

E