

## SPRINKLERS

### Brass Impact Sprinklers (continued)

#### Rain Bird® Key Replacement Parts

NI Part #	Used in Model Numbers:	Description	Reference Number
17000	85 E Series	Bearing Assembly, New H Style, for 1-1/4" part circle impact sprinklers	104640 117376
170141	85 E Series	Bearing Assembly for 1-1/4" part circle impact sprinklers	111136
170135	65D-TNT 65PJ-TNT 65PJADJ-TNT	Bearing Assembly, NPT Assembly, for 1" part circle impact sprinklers	106297
170142	35 Series 35A Series*	Bearing Assembly, New TNT Style, for 3/4" part circle impact sprinklers	110581
170143	25 Series 25B Series**	Bearing Assembly for 1/2" part circle impact sprinklers	106181
17036	25A Series 25BPJ-FP ADJ-DA-TNT	Bearing Assembly for 1/2" part circle impact sprinklers	110950
17000	80 EH 80EW H 80EH-LA 80EWH-LA	Bearing Assembly, H Style, for 1-1/4" full circle impact sprinklers	104640
17000	80 E TNT 80EW TNT	Bearing Assembly, Old TNT Style, for 1-1/4" full circle impact sprinklers	104640
17013	70EH 70 E TNT 70EWH 70EW TNT 70ESPH	Bearing Assembly for 1" full circle impact sprinklers: Female H Style, NPT Assy	104041
17094	70ESP TNT 70CWH 70CW TNT 70CSPH 70CSP TNT	Male H Style, NPT Assy	108726
17018	40B TNT 40B STD 14070 TNT 14070 STD	Bearing Conversion Kit for 3/4" full circle impact sprinklers	110048
17018	40FC TNT	Bearing Conversion Kit for 3/4" full circle impact sprinklers	110048
17078	L36BH	Bearing Assembly for 3/4" full circle impact sprinklers	104152
170144	L36H	Bearing Assembly for 3/4" full circle impact sprinklers	105833-01
17078	L30H L3030H	Bearing Assembly for 3/4" full circle impact sprinklers	104152
170145	30B TNT 30BW TNT 30BH 30BEH 30BWH 30BEWH	Bearing Assembly, H Style, for 3/4" full circle impact sprinklers	104761

\* Except Model 35A-PJ-TNT Special.

\*\* Except 25BPJ Special.

NI Part #	Used in Model Numbers:	Description	Reference Number
17078	30H 30EH 30WH 30WSH 30EWH 30EWSH 30PSH 30EPSH 30WPSH 30EWPSH 30 TNT 30E TNT 30W TNT 30EW TNT 30WS TNT 30EWS TNT 30PS TNT 30EPS TNT	Bearing Assembly, New H Style, for 3/4" full circle sprinklers	104152
170145	30PWSH 30EPWSH 30PWS TNT 30EPWS TNT	Bearing Assembly, New H Style, for 3/4" full circle sprinklers	104761
11078	30 TNT Series	Bearing Adapter for 3/4" full circle sprinklers	110030
170146	29JH 1/2" 29B TNT 1/2" 29JH LA 1/2" 29B TNT LA 1/2"	Bearing Assembly for 1/2" full circle impact sprinklers	104919
170147	20AH 20A TNT ALUM	Bearing Assembly, H Style, for 1/2" full circle impact sprinklers	104189
170148	20AH PM ALUM	Bearing Assembly, H Style, for 1/2" full circle impact sprinklers	104792
170149	L20H M20H	Bearing Assembly for 1/2" full circle impact sprinklers	104695
170148	L20H-PM M20H-PM	Bearing Assembly for 1/2" full circle impact sprinklers	104792
170147	L20VH M20VH	Bearing Assembly for 1/2" full circle impact sprinklers	104189
170150	L20VH-PM M20VH-PM	Bearing Assembly for 1/2" full circle impact sprinklers	104885
170148	14DH 14D TNT 20-14H-PM	Bearing Assembly for 1/2" full circle impact sprinklers	104792
170149	14JH 20-14 H 20C TNT 20ECTNT 20 JH 20 EJH	Bearing Assembly for 1/2" full circle impact sprinklers	104695
170151	20 ADJ-B 20ADJ 20 L (A)	Bearing Assembly for 1/2" full circle impact sprinklers	109220
170147	14VH 14V TNT 14V LA TNT	Bearing Assembly, New H Style, for 1/2" full circle impact sprinklers	104189

F